

Retaining Ring Kits

RPK#4 Retaining Ring Kit

Contains the following styles of retaining rings:





Rotor Pack (RPK#4)



Rotor Pack features 1,000 retaining rings in four durable, clear-plastic boxes with easy snap on/off lids. Boxes fit into slots on a plastic holder which folds in half into a convenient, portable carrying case.

Rotor Pack contains internal ring sizes that will fit housings/bores from 3/8" in diameter to 1-1/8". External rings in the kit will accommodate shaft sizes from 1/4" to 1-1/8". Contains 2 pliers to fit every ring in the kit.

ROTOR PACK - RPK #4

Rotor Clip	Housing	Qty.	Rotor Clip	Shaft	Qty.
Number	Dia. (In.)		Number	Dia. (In.)	
H0-37	3/8	50	SH-25	1/4	50
H0-43	7/16	50	SH-31	5/16	50
HO-50	1/2	50	SH-37	3/8	50
HO-56	9/16	50	SH-43	7/16	50
H0-62	5/8	50	SH-50	1/2	50
HO-75	3/4	50	SH-56	9/16	50
H0-87	7/8	50	SH-62	5/8	50
HO-100	1	50	SH-75	3/4	50
H0-112	1-1/8	50	SH-87	7/8	50
			SH-100	1	50
			SH-112	1-1/8	50

RPK#5 "E" Retaining Ring Kit

Contains the following styles of retaining rings:





Rotor Pack, Jr. (RPK#5)

Rotor Pack Jr. contains over 1,500 "E" retaining rings in four durable, clear plastic boxes with easy snap on/off lids. Boxes fit into slots on a plastic holder which folds in half into a convenient, portable carrying case.

Rotor Pack Jr. contains "E" rings

accommodating shaft sizes from 1/16" in diameter to 1-3/16".

ROTOR PACK JR. - RPK#5

Rotor Clip		Qty.	Rotor Clip	Shaft	Qty.
Number	Dia. (In.)		Number	Dia. (In.)	
E-6	1/16	200	E-62	5/8	40
E-9	3/32	150	E-75	3/4	15
E-12	1/8	150	E-87	7/8	15
E-14	9/64	100	SE-9	3/32	150
E-15	5/32	100	SE-11	7/64	150
E-18	3/16	100	SE-17	11/64	100
E-25	1/4	50	SE-21	7/32	50
E-37	3/8	50	SE-31	5/16	50
E-43	7/16	50	SE-98	63/64	15
E-50	1/2	40	SE-118	1-3/16	12

Please wear protective eyeware while installing and removing retaining rings & hose clamps.